

## Mounting the mirror 22" / 24"

Place the mirror on a clean surface and check which side is mirrored (there is no distance between object and mirror image). Put this side up.



Have rubber profiles and stainless steel pressure strips ready.



Put on the rubber profiles.



Turn the monitor on its back and lead the cables away to the side so that they are not squeezed.



Put spacer 3 mm (rubber, carton) on the round tube and insert the mirror with the attached rubber profiles into the groove of the mirror holder.

**IMPORTANT!** The mirrored side faces the upper monitor.

Push the mirror onto the spacers.

The mirror rubber must be flush with the mirror holder.



## Mounting the mirror 22" / 24"

Insert the pressure strips between the bottom of the groove (screw side) and the rubber profile.

Tighten the Allen screws. Always alternate left and right from bottom to top screws to prevent tension from building up in the mirror  
When working with the cordless screwdriver: Torque 2.

Remove the spacers again.  
Set up the monitor.

